

# Danfoss Icon™ Master Controller 24V



**1.**

1.1

1.2

1.3

1.4

1.5

**2.**

2.1

2.2

2.3

2.4

**3.**

3.1

3.2

**4.1**

**4.2**

**5.**

**6.**

**7.**

**8.**

**9.**

**10.**

**11.**

**12.**

**13.**

**14.**

**15.**

**16.**

**10.**

**Cable pin out**

1	2	3
---	---	---

1. GND  
2. COM A  
3. COM B

**17. Cable/wiring** Danfoss Icon™ Master Controller 24V

**24V**

2 x 2 x Ø 0,6 PDS cable (UTP or STP)	☺
H03VV-F 0,50 mm <sup>2</sup> , flexible	☺
H03VV-F 0,75 mm <sup>2</sup> , flexible	☺
3 x 1,0 mm <sup>2</sup> , solid core	☺
3 x 1,5 mm <sup>2</sup> , solid core	☺
5 x 1,5 mm <sup>2</sup>	☹
> 1,5 mm <sup>2</sup>	☹
< 24 AWG	☹

**18.1**

**18.2**

**18.3**

AQ33143269482800-000102 | 088N2113 01

© Danfoss | FEC | 2020.12